

Test Report

Available test-cases: 15

Conducted test-cases: 15

Passed test-cases: 10

Failed test-cases: 5

Test_user:

E-Mail: 123

Password: 123

Test Specification

1. Testcase

Linked to requirement: REQ_001, REQ_003, REQ_006, REQ_022

Test-description:

- 1. Start the application. Enter the main screen.
- 2. Check the availability of these three buttons.
- 3. Click Check-in button
- 4. Check if the check-in button is still clickable after it is clicked
- 5. Click Check-out button
- 6. Check if the check-out button is still clickable after it is clicked
- 7. Check if the motion profile hint is visible

Expected results:

- At 2: 3 buttons: check-in, check-out, pause notifications are available.
- At 3: button should be clickable
- At 4: button should be unclickable
- At 5: button should be clickable
- At 6: button should be unclickable
- At 7: textbox is visible and showing the actual movement


Partial results:

At 2: passed At 3: passed At 4: passed

At 5: passed At 6: passed

At 7: passed

Testcase result: passed



2. Testcase

Linked to requirement: REQ_002_REQ_022





Test description:

- 1. Start the application. Enter main screen
- 2. Click on check-in
- 3. Click on notification switch to switch off notification
- 4. Click on remind me

Expected results:

At 3: notification switch show: Notification OFF

At 4: No notification will go through

Partial results:

At 3: passed

At 4: passed

Testcase result: passed

3. Testcase

Linked to requirement: REQ_004

Test description:

- 1. set in the code that after 10 seconds in the same movement, a notification will be sent
- 2. enter the app, enter main screen
- 3. click check-in button
- 4. wait 10 seconds

Expected results:

At 3: clickable

At 4: a notification saying: let's change movement

Partial results:

At 3: passed

At 4: failed

Testcase result: failed

4. Testcase

Linked to requirement: REQ_005, REQ_007, REQ_022

Test description:

- 1. Enter the app, enter main screen
- 2. Click on check-in
- 3. Check if all 5 motivation tasks are visible
- 4. Click the first 3 motivation tasks
- 5. Click remind me button

Expected results:





At 2: clickable

At 3: all tasks should be visible

At 4: clickable

At 5: the tasks clicked should be reminded as a notification

Partial results:

At 2: passed

At 3: passed

At 4: passed

At 5: passed

Movement Analysis

You are SITTING.

Click to check-in Click to check-out Notification ON









software 40+: male run1 software 40+: male run2 software 40+: male run3 software 40+: male run4 software 40+: male run5

Remind Me



Title

Please don't forget to do: software 40+: male run1, and software 40+: male run2, and software 40+: male run3

Testcase result: passed

5. Testcase

Linked to requirement: REQ_008, REQ_023, REQ_022

Test description:





- 1. Enter app, enter main screen
- 2. Click on settings
- 3. Click on notification settings
- 4. Click on 1 hour

Expected results:

At 2: clickable

At 3: clickable

At 3: visible and clickable

Partial results:

At 2: passed

At 3: passed At 3: passed Testcase result: passed **Notification Settings**

1 Hour

2 Hours

6. Testcase

Linked to requirement: REQ_009

Test description:

- 1. Enter app, enter main screen
- 2. Click check-in
- 3. Wait for movement analysis to start
- 4. Enter database type SELECT*FROM movement

Expected results:

At 2: clickable

At 3: start analyzing, and movement profile change accordingly

At 4: data should be recorded in the database

Partial results:

At 2: passed



Settings

Notification Settings

User Profile

Edit User Profile

Return To Main Screen



At 3: passed

At 4: passed

Testcase result: passed

Movement Analysis

You are now: walking

Click to check-in Click to check-out Notification ON







7. Testcase

Linked to requirement: REQ_009, REQ_010, REQ_011, REQ_012

Test description:

- 1. Enter the model.py file
- 2. Click on line 143
- 3. Click on data folder

Expected results:

At 2: data should be divided every 5 values (T_x is 5 for me)

At 3: data should be split into sit, walk, run, and should be provided by different persons (with different body shape) and different phones

Partial results:

At 2: passed

At 3: passed

Testcase result: passed





✓ data

✓ run

Ⅲ run1.csv

Ⅲ run2.csv

Ⅲ run3.csv

Ⅲ run4.csv

Technologie Campus Cham

```
■ Running.csv
                                                                       ∨ sit
        print(np.shape(X))
                                                                        sit1.csv
        print("shape of Y = " , end = '')
                                                                        sit2.csv
        print(Y)
                                                                        sit3.csv
        print(np.shape(Y))
                                                                        sit4.csv
    return X,Y
                                                                        sit5.csv
                                                                        sit6.csv
                                                                        sit7.csv
X, Y = read_data('data',5)

∨ walk

                                                                        walk1.csv
print(X,Y)
                                                                        walk2.csv
                                                                        walk3.csv
def NormalizeData(data):
                                                                        walk4.csv
    return (data - np.min(data)) / (np.max(data) - np.min(data))
                                                                        walk5.csv
```

8. Testcase

Linked to requirement: REQ_013, REQ_023, REQ_022

Test description:

- 1. Enter app, enter main screen
- 2. Click on settings button
- 3. Click on User Profile button

Expected results:

At 2: clickable

At 3: clickable and displaying correct values

Partial results:

At 2: passed

At 3: passed


Testcase result: passed

9. Testcase

Linked to requirement: REQ_014, REQ_017

Test description:

- 1. Enter app
- 2. Click on sign up button
- 3. Enter accordingly: 321, 321, 321, 321, 321, 321, Male, software engineer
- 4. Click sign up button
- 5. Click I agree







- 6. Enter in login text box 321, password text box 123
- 7. Click login
- 8. Delete all entries
- 9. Enter in login text box 321, password text box 321
- 10. Click login

Expected results:

- At 2: clickable, and enter signup screen
- At 3: all textboxes should be clickable and writable
- At 4: acknowledgement page pops up
- At 5: enter login page
- At 7: button not clickable
- At 10: enter main screen

Partial results:

- At 2: passed
- At 3: passed
- At 4: passed
- At 5: passed
- At 7: passed
- At 10: passed

Acknowledgement
ack1
ack2
ack3
I agree

Testcase result: passed

Sign Up Now!
Enter Your Email
Enter Your New Password!
Re-enter Your New Password!
Name
Age
Weight (in kg)
Height (in cm)
Gender (Male/Female)
Job Position
➤ Register ➤ Back





10. Testcase

Linked to requirement: REQ_015

Test description:

1. Enter database

2. Enter SELECT * FROM password

Expected results:

At 2: all password should be invisible

Partial results:

At 2: failed

Testcase result: failed

11. Testcase

Linked to requirement: REQ_016, REQ_024

Test description:

- 1. Enter app, enter main screen
- 2. Click on settings button
- 3. Click on Edit user profile button
- 4. Click on Gender and enter English word: Female
- 5. Click on age and enter 50
- 6. Click on save changes button
- 7. Click on return to main screen button

Expected results:

On 2: Clickable, Enter Settings screen, with correct motivation tasks

On 3: clickable, enter edit user profile screen

On 4: clickable and writable

On 5: clickable and writable

On 6: clickable and return to settings screen

On 7: clickable and return to main screen with correctly displayed motivation tasks

Partial results:

On 2: passed

On 3: passed

On 4: passed

On 5: passed


On 6: passed






On 7: passed

Testcase result: passed





12. Testcase

Linked to requirement: REQ_021, REQ_022

Test description:

1. Enter app, enter main screen





2. Click on Graph button

Expected results:

At 2: clickable, enter graph screen

Partial results:

At 2: passed

Testcase result: passed

13. Testcase

Linked to requirement: REQ_018

Test description:

1. Enter app, enter main screen

Expected results:

At 1: a notification to allow sensors

Partial results:

At 1: failed

Testcase result: failed

14. Testcase

Linked to requirement: REQ_019, REQ_020

Test description:

1. Enter database

2. Write SELECT*FROM week

Expected results:

At 2: should return all movement profile from the past week

Partial results:

At 2: failed

Testcase result: failed

15. Testcase

Linked to requirement: REQ_021, REQ_022

Test description:

- 1. Enter app, enter main screen
- 2. Click on graph button





3. Click on daily button

Expected results:

At 2: clickable and enter graph screen

At 3: clickable and display a graph of daily movement

Partial results:

At 2: passed

At 3: failed

Testcase result: failed

